

PATCH	CONSOLE	INSTRUMENTS	MICROS	REEMPL.	PIEDS	NOTES
	1	KICK IN	SM91	BETA 91		
	2	KIK OUT	AUDIX D6	BETA 52	PPP	PPP=Petit pied perchette
	3	SN TOP	BETA 57A	SM 57	PPP	
	4	SN BOTTOM	C535	SM 57	PPP	
	5	HH	C451	SM81	PPP	
	6	TOM 1	E904	E604		
	7	TOM 2	E904	E604		
	8	TOM 3	E904	E604		
	9	OH L	C414	KM 184	GPP	GPP=Grand pied perchette
	10	OH R	C414	KM 184	GPP	
	11	PAD	DI			Quadriplette 220V
	12	BASS	DI			Quadriplette 220V
	13	GTR AMP 1	E906	SM 57	PPP	Quadriplette 220V
	14	GTR AMP 2	E906	SM 57	PPP	
	15	KEY 1L	DI			Quadriplette 220V
	16	KEY 1R	DI			
	17	KEY 2L	DI			Quadriplette 220V
	18	KEY 2R	DI			
	19	SAX	ATM350	DPA 4099		
	20	CLARINETTE	C535	SM 57	GPP	
	21	AC GT	DI			
	22	BACK VOC	SM 58		GPP	
	23	LEAD	<b>BETA 57A</b>		GPPL	Grand pied perche longue
	24	BV SAX	SM 58		GPP	
	25	BV GTR	SM 58		GPP	<b>CIRCUITS MONITORS</b>
	26					<b>AUX 1 : SAX</b>
	27					<b>AUX 2 : BACK VOCAL</b>
	28					<b>AUX 3-4 : LEAD</b>
	29					<b>AUX 5 : GUITAR</b>
	30	TB	FOURNI			<b>AUX 6 : KEY 1</b>
	31	INTRO L	MINIJACK L			<b>AUX 7 : DRUMS</b>
	32	INTRO R	MINIJACK R			<b>AUX 8 : BASS</b>